

OMRON DIGITAL TIMER (H5F)

FAQS AND TROUBLESHOOTING GUIDE

MY TIMER ISN'T DISPLAYING THE RIGHT DAY OR TIME?

1. First check to see if power ("PW") is displayed on the screen.
2. Check that the day and time (AM/PM) are correctly displayed on the screen.
3. Ensure the switch is set to "AUTO".
4. If the above are correct, try manually changing the time. Refer to "SETTING OR ADJUSTING THE TIME" in the appendix.
5. If adjusting for Daylight Savings Time (DST), use a pen to press the +1h Key, the present time will switch between the (standard) present time to/from (+/-) the summer time.

I ADJUSTED MY TIMER FOR THE MOST RECENT DAYLIGHT SAVINGS BY PRESSING THE "+1H" KEY AND THE TIME DISPLAYED ON SCREEN IS NOT CORRECT?

To manually change the time, refer to "SETTING OR ADJUSTING THE TIME" in the appendix.

DOES MY TIMER HAVE A WARRANTY?

Yes, there is a lifetime warranty* on the timer for as long as the customer owns the property where the timer was installed.

DOES MY TIMER HAVE A BATTERY BACK UP IN CASE THERE IS AN UNEXPECTED POWER OUTAGE?

It will last up to 5 years with no power source and will handily get you through any power interruption.

HOLIDAYS

IMPORTANT NOTE:


Your electrical meter knows it's a holiday, so any electricity you consume on holidays will be charged at the off-peak rate.

MY ELECTRIC THERMAL STORAGE ("ETS") UNIT IS DISPLAYING A "P" VS. "C"?

Although the "P" displayed on the ETS unit indicates a peak time, you are not being charged peak rates. This will occur when a holiday is observed on a weekday. Don't worry, if your ETS unit needs to charge, its internal timer will allow it to come on at 12 noon and charge until 4 pm. The reason for this, is the timer is not pre-programmed with holidays, meaning your ETS does not know it's a holiday and is treating it like regular weekday in terms of when it charges and what is displayed.

I RAN OUT OF HOT WATER, WHAT SHOULD I DO?

If you have a Steffes unit display like the one pictured to the right, you can simply "enable" the "zone" that your water heater is on then press the "start/stop" override button to manually charge your hot water heater. You will be charged off-peak rates for all electricity consumed on holidays




For more information about your new timer and Time-of-Day rates visit www.nspower.ca/ets or call 1-800-428-6774



APPENDIX

SETTING OR ADJUSTING THE TIME

1. Press and hold the **MODE** Key for 2 seconds to enter the time adjustment mode. The ☰ symbol will flash on the display.
2. To change the day of the week, move the ▼ symbol to the correct day using the **d** Key. Change the time to the correct time by pressing the **h** and **m/pwd** keys. Ensure that you have the correct AM or PM. If you are adjusting the timer for Daylight Savings Time (DST), see below.




3. Press the **WRITE** Key. The colon on the display flash and the clock will start. Press the **MODE** Key 3 times to return to the run mode. Note: The set time is enabled when the **WRITE** Key is pressed.



ADJUSTING THE TIMER FOR DAYLIGHT SAVINGS TIME (DST)

1. Using a pen, press the **+1hr** Key. This will change the time to DST in the spring and back to Standard time in the fall.



STANDARD TIME (NOVEMBER - MARCH)



DST (MARCH - NOVEMBER)



For more information about your new timer and Time-of-Day rates visit www.nspower.ca/ets or call 1-800-428-6774

